


SIWS USE Quick Reference

A detailed PDF version of this help document is available on the computer desktop

SIWS Power On Sequence

AV Mute
- Temporarily black out screen

Volume Control
- Turn knob to adjust volume



POWER ON

1 – Press **GREEN** “ON” (red LEDs will begin flashing and all panel functions will lock out for 30 seconds until projector warms up). PC input will automatically be selected.

POWER OFF

2- Press **RED** “OFF” button

NEED HELP Dial 7222

DOCUMENT CAMERA USE



Power On Sequence

1 – Turn on the main power switch of the document camera. Power light will turn from red to green.

2- Select “DOC

3- Use Zoom and rotate functions as required

DVD USE




1 – Press “Power” on VCR

2- Select “DVD”



3- Use DVD functions as required

VCR USE





- 1 – Press “Power” on VCR
- 2- Select “VCR”
- 3- Use VCR functions as required

Annotation USE



- 1 – Press “Power” on Smart Panel
- 2- Select “PC”
- 3- Use Annotation functions as required – use mouse or shortcut buttons to perform desired functions

Caption Decoder USE



- Caption decoder is located in rack next to VCR and is used during VCR playback
- 1- Select “VCR”
 - 2- Rotate knob on caption decoder to activate desired caption decoder setting


Interactive screen

Touch the screen with the pen tool to control computer applications or write in digital ink.




Save function

Capture your work to Notebook software as a screen shot that you can edit, or save your notes directly into several software applications, including Windows versions of Microsoft PowerPoint, Word, and Excel, or into AutoCAD software.



SMART Board tools

Add even more features and flexibility to your interactive whiteboard session. Customize settings, type with the On-Screen Keyboard, write over digital video and much more. Features include LinQ™ software, Start Center, SMART Video Player, SMART Recorder, Floating Tools, Spotlight, and On-screen Keyboard.



Pen-tool and function buttons

Use pen-tool buttons on the console to change ink color quickly or activate the eraser without launching software and crowding the screen with extra toolbars. Use function buttons for quick access to common functions.



Notebook whiteboarding software

Create, organize and save notes, drawings and screen captures. Access thousands of free images and templates, interactive and educational content, advanced drawing tools and more from an easy-to-use interface.

